



Cutter



Scraper



Felt edge
squeegee



Sprayer



Squeegee

Ref. produit :
KITbat

1 Perfectly clean the windows



Spray soapy water on the window for cleaning it and use the scraper to get-off potentials residues. Then, carefully wipe the windows thanks to a dry and clean cloth. Don't forget the edges and corners.

2 Take-off the protective liner



Use 2 pieces of tape (not supplied) placed in a corner opposite each other to separate the 2 parts. While you gently split off the film, profusely spray the adhesive side with soapy water

Each films are with cardboard or transparent liner

3 Set the film on the window



Moisten with soapy water the window to be equipped. Flip the film by applying the wet side to the glass, taking it from the top. Once the film flipped, spray with soapy water for slipping the felt edge squeegee.

4 Squeegee the film



Smooth the film thanks to the squeegee from the centre to the outside, starting at the top

5 Recut if necessary



Use the felt edge to guide the cutter when cutting so that it doesn't touch the frame. And, squeegee again.



The installation is complete !

