



Cutter



Scrapper

Felt edge  
squeegee

Sprayer



Squeegee

Ref. produit :  
**KITbat****2 persons**  
recommended  
for installation

## 1 Perfectly clean the windows

Spray with soapy water and use a scraper. Wipe the glass and frame with a clean, dry cloth.

**i** *Tip: In the spray bottle, mix a teaspoon of liquid soap with 500ml of water.*

## 2 Preparing the adhesive film

Place the film on a larger surface (or on another window).

Place the film with the protective film facing you (marking sticker facing you).

## 3 Take-off the protective liner

Remove 10 cm of the protective liner from the top. For dry installation, it is not necessary to moisten the film.

**i** *Tip: use 2 pieces of tape (not supplied) placed at an angle opposite each other to separate the 2 parts.*

## 4 Set the film on the window

Turn the film over, applying the adhesive side to the glass to be fitted, taking it from the top.

## 5 Squeegee the film

Smooth the film using the felt-tipped trowel from the centre outwards, starting at the top and removing the protective liner as you go.

## 6 Recut if necessary

Use the flask to guide the cutter when cutting so that it no longer touches the frame and re-moisten the cut edges.

**The installation is now over !**