



Cutter



Sprayer



Squeegee

Ref. product  
**KITwall****2 persons**  
recommended  
for installation

## 1 Preparing the surface

Make sure the surface is smooth and clean. Ideally, the wall should be sanded and painted (one coat is sufficient).

**i** *Tip: protect walls and ceiling with tape to avoid marks when cutting off excess wallpaper*

## 2 Making your mark

Using a tape measure, a level and a pencil, mark the width of the first strip and then draw a straight line as a reference point.

**i** *Tip: choose to apply the sheet in a corner near the main light source*

## 3 Apply the 1st strip

Activate the wallpaper paste: spray the back of the wallpaper and the wall with plenty of water. Place the strip on the wall to be covered, following the markings you have made. Mould to eliminate bubbles: from the inside to the outside, from the top to the bottom.

## 4 Trim the excess

Using a cutter and the squeegee, cut out the offcuts at the ceiling and skirting boards.

**i** *Tip: Any glue residue should be cleaned up immediately with a damp sponge and lukewarm water.*

## 5 Apply the following strips

Repeat the steps of activating the adhesive, applying the trowel and removing the scraps for the next strips.

**i** *Tip: make edge-to-edge seams between the strips so that they are as discreet as possible.*

**The installation is complete !**