

**Essentials
accessories**

Ref. produit : **KITbat**

2 persons
recommended
for installation

2 Installation



3. Cut-outs

Cut the film exactly to size before installation. This step prevents any risk of splitting the film.



4. Cleaning

Clean the glass perfectly. Spray with soapy water and use a scraper. Wipe glass and frame with a soft cloth.



5. Liner separation

Separate the protective film from the foil.

 Use 2 pieces of tape (not supplied) placed at an angle opposite each other to separate the 2 parts.



6. Neutralize the glue

While carefully removing the film, spray the adhesive side with plenty of soapy water.

 Moisten your fingers to prevent dusting



7. Position the film

Moisten the glass to be fitted to be fitted. Turn the film over, applying the wet side to the glass, taking it from the top.

 Once the film has been applied, spray with soapy water to make the maroufle glide.



8. Scrap the film

Smooth the film using the maroufle with handle from the center outwards, starting at the top.


The installation is complete !
