



1

Installation material :

Check that there are 2 or 3 fixings depending on the width of the blind. They will be placed on the bar of the film blind.



2

Take your measurements: plan the holes at 10 / 15 cm from the ends of the fixing bar.



3

Then make your markings for the holes.



4

Proceed with the drilling.

Remember to put the fasteners* downwards.



5

Once you have screwed in your 2 fixings, you simply clip on the film blind fixing bar directly.



6

Check that the blind is level.



7

Then check that the blind is lowered with the help of the chain.



8

Position your limit switch:

Lower the awning to its lowest position and clip the stop onto the chain.

Reassemble the blind and clip on the second stop.



9

Enjoy your brand new anti-glare film blind!

 **The installation is complete !**

* As a reminder, screws are not supplied as they will depend on the surface to be drilled.

