



How to install ?
VIDEO HERE



Have you taken the
correct measures ?
CHECK HERE



Cutter



Scraper



Felt edge
squeegee



Sprayer



Squeegee

Product ref :
KITbat

1 Clean your glass windows perfectly



Spray the glazing with soapy water and scrape off any impurities. Add more soapy water and wipe off any remaining residue with a window scraper. Dry with a clean, dry cloth.

i Clean the frames too

2 Remove the film's protective liner



Use 2 pieces of tape (not supplied) placed at an angle opposite each other to separate the 2 parts. While carefully removing the protective film, spray the adhesive side with plenty of clean water.

i The side of the protective film is indicated by a coloured dot.

3 Place the film



Take care to apply the wet side against the glass, taking it from the top. Slide it over the glass to position it at an angle and start smoothing it by hand.

i Once the film is in place, spray with water to make the clump slide.

4 Stamp the film



Smooth the film using the Felt edge squeegee from the centre outwards, starting at the top.

5 Redécoupez si nécessaire



Use the Felt edge squeegee to guide the cutter as you cut so that it no longer touches the frame, then press down again.



The installation is **complete !**

